Header Bars



Pressure Staggered



Pressure Straight



General Specifications:

The header bars shall be equipped with emergency high pressure shutoff valves to allow for emergency isolation of the header bars. The header bar shall incorporate integral check valves for each station.

NOTE: The header bar comes with universal mounting brackets to be mounted direct or with a 12" wall spacing when the optional wall mounting bracket is used. The header bar mounting brackets are optional accessories.

All header bars and pigtails shall be cleaned for oxygen service.

Features:

• CGA gas specific header bar with an option to add integral check valves and cylinder pigtail assemblies for future expansion. Fittings are sold separately.

Model Numbers

M2-HBYY-XXL-XXX

The Letters "YY" Define the Type of **Header-Bar Assembly:**

"TS" = Straight c/w Stainless Pigtails

"TC" = Straight c/w Copper Pigtails

"XS" = Staggered c/w Stainless Pigtails

"XC" = Staggered c/w Copper Pigtails

"LO" = Liquid c/w Cryogenic Pigtails

"L" Defines the Language:

E = English (CSA)

IJ = English (NFPA)

The Letters "XX" Define the **Number of Cylinders:**

e.g. 4 x 4 use 08

M-X-HB-WLBRKIT

"XXX" defines the Type of Gas:

Oxygen = OXYNitrogen = NIT

Medical Air = AIR

Carbon Dioxide = CO2Nitrous Oxide = N20

Helium = HEL


Argon = ARG

Mixed Gas =MIX


Wall Bracket for Header-bar Assembly:




Technical Specifications







Long configuration




Note:

- Dimensions are based on approximate distance
- Floor stand and wall mounting brackets are optional accessories
- Dimensions for the manifold cabinet are based on Amico manifold P-M2LD series



3

Technical Specifications



Amico Corporation 85 Fulton Way, Richmond Hill, ON L4B 2N4, Canada I 71 East Industry Court, Deer Park, NY 11729, USA Toll Free Tel: 1.877.462.6426 | Toll Free Fax: 1.866.440.4986 Tel: 905.764.0800 | Fax: 905.764.0862

AL-SP-HDR-BRS JAN 2013 www.amico.com